



PRODUCT: SEQUENTIAL LED SPOILER LIGHT

P/N: SPL0110 AND SPL2012

PROPER OPERATION:

Please take the time to test the light properly. We have received reports that this light is not working correctly, however, this is due to improper testing.

Some customers are reporting that when you turn on the right turn signal the running light goes out but when you turn on the left turn signal the running light feature stays on.

See below why this is happening.

PLEASE FOLLOW THESE STEPS IN TESTING THE LIGHTS:

The turn signal indicator in the spoiler led light flashes when the turn signal switch is moved to the right or left and the opposite side RED LEDs stay on.

➤ When testing the signals with the bike stationary, the requested turn signal must be cancelled by pushing in the turn signal switch. If the request is not properly cancelled, the RED LEDs will not stay on.

The opposite side signal can be activated by moving the turn signal switch to the opposite side. The YELLOW LEDs will flash and the RED LEDs will stay on.

➤ While riding the bike, the turn signal self cancels when:

- A specific distance is traveled or
- A specific amount of time goes by or
- The request to signal is cancelled by pushing the switch in.

➤ When the **four-way emergency flasher** is pressed, only the amber turn signals will be activated.